


## USING THE SYSTEM

- a. Use the system with the vehicle ignition ON or the ignition in ACC Mode
- b. Slide the OPEN LATCH to release the monitor.
- c. Manually position screen for optimum viewing. The unit will turn on automatically.
- d. The unit will default to INTERNAL DVD, if not, press the Source Button on the unit or remote to select INTERNAL DVD.
- e. Insert a compatible disc, label side up, into the unit.
- f. Some discs will start playback automatically, if not, follow the on screen instructions.



## USING EXTERNAL SOURCES

- a. Connect the RCA audio and video outputs of the device to the Rosen RCA adapter cable.
- b. Plug into the AUX input port on the side of monitor.
- c. Press SOURCE until "AUX" appears on the screen.



## USING THE WIRELESS HEADPHONES

- Press the ON/OFF button on the ear piece, the button will illuminate when the headphones are on.
- If the button does not illuminate, insure the batteries are fresh and installed correctly.
- Adjust the volume by rotating the volume control wheel.



## PLAYING AUDIO OVER THE RADIO

- Press the SPEAKER button to enable playback through the radio.
- Note the FM frequency displayed on the screen, adjust the vehicle radio to match the indicated FM frequency.
- Adjust the radio volume to the desired level.



*This sequence must be repeated each time the vehicle is turned off or the monitor is closed.*